# -**DYN/1MO** (7E/7F/7G)

We have pursued top-level performance that carries on the excellence of the T-matic cylinder, our top-selling pneumatic actuator for butterfly valves. Employing an NAMUR mount, this unit is compact and lightweight, and offers high output and further heightened perfection as a complete system.



#### Features

- Direct valve installation with bottom ISO mounting.
- Completely direct mounting of valve installation section.
- NAMUR mount at pneumatic port connections and accessories interface.

		New T-DY	NAMO St	tandard s	pecificati	ons						
		Double	e-acting typ	oe (7E)		Sin	gle-acting	type (7F / 7	7G)			
Type	T35	T85	T200	T380	T750	T85S	T200S	T380S	T750S			
Torque (N·m)(When supply pressure is 0.4MPa and rotation angle is 0°)	35	85	200	380	750	30	65	116	240			
Supply air pressure condition/temperature		-10 to 60 degrees C										
Air Supply Pressure	0.4 to 0.7MPa											
Body shell max (MPa)					1.05MPa							
Air connection (Rc)					Rc(PT)1/4							
Rotating angle					90°							
Ambient temperature				<del>-</del> 10 f	o 60 degre	es C						
Travel time(sec) with speed controller	1 to 15 sec	2 to 15 sec	3 to 15 sec	7 to 20 sec	12 to 25 sec	2 to 15 sec	6 to 15 sec	8 to 20 sec	15 to 25 sec			

<sup>\*</sup>The opening and closing times are the times in the case of a single unit of a cylinder with a standard speed controller (SP-K017-Z03-006) and a solenoid valve (PCS2408-03-100MC) when the air supply pressure is 0.4MPa. The opening and closing times depend on pneumatic piping system, etc.


#### **New T-DYNAMO Principle of operation**


#### ■ Double-acting type cylinder

- (1) The cylinder space which is enclosed by the case ① and the covers® and ⑦ is divided into airtight chambers (a) and (b) by the pistons (5) and the piston packing (2).
- (2) The shaft ② penetrates the chamber ⑤ of the case. The yoke ③ is fitted in the hole across the shaft in such a way that it allows it to slide in the hole. The top of the yoke is connected with the parallel pins @ so it rotates in accordance with the movement of the pistons.
- (3) The compressed air enters chamber (a) through port A and pushes the pistons. The air in chamber (b) is exhausted through port B as the pistons move due to a pressure difference between the two chambers. Integrated with these pistons, the parallel pins @ also move and torque in the shaft is generated.


#### ■Single-acting type cylinder


- (1) The cylinder space which is enclosed by the case ① and the covers⑥ and ⑦ is divided into airtight chambers (a) and (b) by the pistons (5) and the piston packing (2).
- (2) The shaft ② penetrates the chamber ⑤ of the case. The yoke ③ is fitted in the hole across the shaft in such a way that it allows it to slide in the hole. The top of the yoke is connected with the parallel pins ② so it rotates in accordance with the movement of the pistons.
- (3) The compressed air enters chamber (b) through port B and pushes the pistons. The air in chamber (a) is exhausted through port C as the pistons (5) move and the spring (42) is squeezed due to a pressure difference between the two chambers. Integrated with these pistons 5, the parallel pins 2 also move and torque in the shaft is generated.
- (4) When air supply to Port B is stopped, the pistons are pushed back due to the force of the spring @ and torque in the shaft is generated.





#### **New T-DYNAMO Dimensions**





#### **New T-DYNAMO Dimension list**

Culir	nder type				[	Dimer	nsion	(mm)					Cylinder	
Cylli	idei type	Α	P1	P2	НЗ	C1	C2	f1	f3	S	MG	N	(litter/st)	
T35	P.C.D.70	202.5	112	90.5	125	80	30	57	35	12	M8	13	0.2	1.7
T85	P.C.D.70	251	134	117	168	80	30	75	51	14	M8	17	0.5	4.6
100	P.C.D.102	231	134	117	100	00	30	75	51	14	M10	20	0.5	4.0
T200	P.C.D.70	320.5	170	150.5	203	80	30	79	51	18	M8	15	1.1	7.9
1200	P.C.D.102	320.3	170	150.5	203	00	30	19	31	10	M10	20	1.1	7.9
	P.C.D.70										M8	15		
T380	P.C.D.102	397.5	208.5	189	231	80	30	91	62.5	24	M10	18.5	2.1	14
	P.C.D.125										M12	20		
	P.C.D.102										M10	18.5		
T750	P.C.D.125	520.5	276	244.5	269	80	30	118	70	24	M12	23	4.6	24
	P.C.D.140										M16	28		


#### **New T-DYNAMO Dimension list**


Cylin	nder type					Dimer	sion	(mm)					Cylinder	Approx. Mass
Cylli	idei type	Α	P1	P2	НЗ	C1	C2	f1	f3	S	MG	N	(litter/st)	
T85S	P.C.D.70	338.5	181	157.5	168	80	30	75	51	14	M8	17	0.5	6.2
1000	P.C.D.102	330.0	101	157.5	100	00	30	75	31	14	M10	20	0.5	0.2
T200S	P.C.D.70	423.5	223	200.5	203	80	30	79	51	18	M8	15	1.1	10.7
12003	P.C.D.102	423.5	223	200.5	203	00	30	19	31	10	M10	20	1.1	10.7
	P.C.D.70										M8	15		
T380S	P.C.D.102	524.5	273.5	251	231	80	30	91	62.5	24	M10	18.5	2.1	18.9
	P.C.D.125										M12	20		
	P.C.D.102										M10	18.5		
T750S	P.C.D.125	697.5	363	334.5	269	80	30	118	70	24	M12	23	4.6	32.4
	P.C.D.140										M16	28		


**Actuator** New ELMY
41
New MICOM ELMY II
41
PMK-SRF
4K SRJ 4J LTKD 4L New T-DYNAMO 7E/7F/7G TGA 3A TG-S 3K/3U **3C** Diaphragm 6X/6W/6Z/6A/6B Hydraulic cylinder 3 H Manual Actuators 1T/1J/2U/2I/2S/2G/2R



#### New T-DYNAMO Output torque curves







- $\ensuremath{\boxdot}$  The table shows the torque at an operating air pressure of 0.4 MPa.
- ② Output torque for an operating air pressure of PMPa is given by := P x (torque value obtained from the table)/0.4. (Only double-acting type cylinder)
- ③ In the case of single-acting type cylinders, the spring force does not change even if the operating air pressure is changed. Thus the torque indicated by the dotted lines is constant regardless of the operating air pressure.
- ④ In the case of single-acting type cylinders, the output torque value at open→close is different from that at close→open. The continuous lines and dotted lines indicate the torques respectively.

	7G (Open with pressure)	7F (Close with pressure)
Continuous line	Torque at close →open with air pressure	Torque at close →open with spring
Dotted line	Torque at open →close with spring	Torque at open →close with air pressure

(5) A valve for the single-acting type cylinder should be selected referring to the torque indicated with a dotted line.

#### **New T-DYNAMO Output torque**

#### **Double-acting type**

 $(N \cdot m)$ 

Typo	S	upply pres	sure (MPa	ı)
Type	0.4	0.5	0.6	0.7
T35	35	43	52	61
T85	85	106	127	148
T200	200	250	300	350
T380	380	475	570	665
T750	750	937	1125	1312


### Single-acting type (spring returned type)

 $(N \cdot m)$ 

			S	upply pres	sure (MPa	ı)			Spr	ring
Туре	0.	4	(	0.5	(	0.6	0	.7	Эрі	ii ig
	0°	90°	0°	90°	0°	90°	0°	90°	0°	90°
T85S	55	30	76	51	97	72	118	93	30	55
T200S	135	65	185	115	235	165	285	215	65	135
T380S	264	116	359	211	454	306	549	401	116	264
T750S	510	240	697	427	885	615	1072	802	240	510

#### **New T-DYNAMO Air Consumption**

VS=(B)



#### (1) Required air consumption

Double-acting type
$$VD=(A+B)\left(\frac{P+0.1013}{0.1013}\right)N$$
Single-acting type
$$VS=(B)\left(\frac{P+0.1013}{0.1016}\right)N$$

- $V\,D$  : Double-acting type cylinder air consumption  $(N\,\ell)$
- VS: Single-acting type cylinder air

- consumption (Nℓ)

  A,B: Cylinder capacity (ℓ)

  P: Working pressure (MPa)

  N: Operating frequencies in a given time
  (1 round trip=1)

# 0.1013

$$\label{eq:cd} \begin{array}{ll} \mbox{Double-acting type} & \mbox{CD=} & \frac{\mbox{VD}}{t} \\ \\ \mbox{Single-acting type} & \mbox{CS=} & \frac{\mbox{VS}}{t} \\ \end{array}$$

- (2) Air consumption within a unit time

  CD : Double-acting type cylinder airconsumption ( $N_{\ell}/\text{sec}$ )
  - CS: Single-acting type cylinder air consumption (N<sub>ℓ</sub>/sec)
  - t : Unit time (sec)

(Note) The compressor should have a larger capacity than air consumption calculated in above (1)and (2).

#### Double-acting type

type	Cylinder ca	apacity (2)
туре	А	В
T35	0.2	0.2
T85	0.4	0.5
T200	0.8	1.1
T380	1.8	2.1
T750	3.2	4.6

#### Single-acting type


tuno	Cylinder capacity (1)
type	В
T85S	0.5
T200S	1.1
T380S	2.1
T750S	4.6





#### New T-DYNAMO Expanded view of component T35 to T750 (double-acting type)

Note: The parts numbers marked with  $\square$  indicate "O-ring set". Please exchange all the parts included in the set.



# New T-DYNAMO Parts list T35 to T750(double-acting type)

#### **■**Double-acting type

N	lo.	Description	Q'ty	Remarks
	1	Case	1	
	2	Shaft	1	
	3	Yoke	1	
	4	Stopper	1	
	5	Piston	2	
	6	Cover 1	1	
	7	Cover 2	1	
	8	Base plate	1	
	9	Bearing	2	
	11	Indicator plate	1	
*	13	Bearing 1	2	T35:1pc
*	14	Bearing 2	1	Only T35
*	15	Bearing 3	1	
*	16	Bearing 4	1	Only T35
*	17	Wear ring	2	
*	18	Piston support	4	
*	19	Thrust plate	1	
	21	Position indicator	1	
	23	Slit cover	1	
*	24	Piston packing	2	
*	25	O-ring (Upper Side)	1	
*	26	O-ring (Lower Side)	1	
*	27	Cover packing	2	
*	29	O-ring (base plate)	1	
*	30	Connecting pin	1	
*	31	Plug	1	
	32	Parallel pin	2	
*	34	C-retainer (lower shaft)	1	Only T85~T750
	35	C-retainer (piston)	2	Only T85~T750
	36	Bearing housing	1	Only T750
	46	Spring washer (cover 1,2)	8	
	47	Hexagon bolt (cover: double-acting)	8	
	49	Hexagon bolt (base plate)	4	T35:2pcs
	50	Spring washer (base plate)	4	T35:2pcs
	51	Hexagon stop screw	1	
	52	Hexagon stop screw	1	
	53	Hexagon socket set screw (open-side)	1	
	54	Hexagon socket set screw (close-side)	1	
	55	Spring washer (close-side stopper)	1	
*	60	Sealing washer	1	


Note: Recommended maintenance parts are indicated by " $\star$ " before the part number. To order a set of recommended maintenance parts, please specify "O-ring set".

Actuator New ELMY
41
New MICOM ELMY II
41
PMK-SRF
4K SRJ 4J LTKD 4L New T-DYNAMO 7E/7F/7G TGA 3A TG-S 3K/3U **3C** Diaphragm 6X/6W/6Z/6A/6B Hydraulic cylinder 3H Manual Actuators 1T/1J/2U/2I/2S/2G/2R



#### New T-DYNAMO Expanded view of component T85S to T750S (single-acting type)

Note: The parts numbers marked with  $\square$  indicate "O-ring set". Please exchange all the parts included in the set.



# New T-DYNAMO Expanded view of component T85S to T750S(single-acting type)

#### Single-acting type

1 Case 1 2 Shaft 1 3 Yoke 1 1	
3 Yoke 1	
4 Stopper 1	
5 Piston 2	
6 Cover 1 1	
7 Cover 2 1	
8 Base plate 1	
9 Bearing 2	
11 Indicator plate 1	
★ 13 Bearing 1 (shaft-piston) 2	
★ 15 Bearing 3 (lower shaft) 1	
★ 17 Wear ring 2	
★ 18 Piston support 4	
★ 19 Thrust plate 1	
21 Position indicator 1	
23 Slit cover 1	
★ 24 Piston packing 2	
★ 25 O-ring (upper) 1	
★ 26 O-ring (lower) 1	
★ 27 Cover packing 2	
★ 29 O-ring (base plate)	
★ 30 Connecting pin 1	
★ 31 Plug 1	
32 Parallel pin 2	
★ 34 C-retainer (lower shaft) 1	
35 C-retainer (piston) 2	
36 Bearing housing 1	
37 Stopper bolt 1	1 01119 11 000
42 Spring 2	
43 Spring guide 2	
44 Hexagon bolt (spring guide) 2	
45 Spring washer (spring guide) 2	
46 Spring washer (cover 1,2) 8	
48 Hexagon socket bolt (cover 1,2) 8	
49 Hexagon socket bolt (base plate) 4	
50 Spring washer (base plate) 4	
51 Hexagon nut (cover 2) 1	
52 Hexagon nut (base plate) 1	
53 Hexagon socket set screw (cover 2) 1	
54 Hexagon socket set screw (base plate) 1	
55 Spring washer (base plate) 1	
★ 60 Sealing washer (cover 2) 1	
62 Hexagon socket tapered plug (cover 1) 1	

Note: Recommended maintenance parts are indicated by "★" before the part number. To order a set of recommended maintenance parts, please specify "O-ring set".

Actuator New ELMY
41
New MICOM ELMY II
41
PMK-SRF
4K SRJ 4J LTKD 4L New T-DYNAMO 7E/7F/7G TGA 3A TG-S 3K/3U **3C** Diaphragm 6X/6W/6Z/6A/6B Hydraulic cylinder 3 H Manual Actuators 1T/1J/2U/2I/2S/2G/2R



# New T-DYNAMO Standard Accessory Combination Chart

#### ■ Double-action cylinder

This chart indicates the accessories than can be used together in conjunction with the double-action cylinder. Only those items with a "O" mark in the same column can be used together.

Device name	Standard spe		Manufacturer	Fig.		_			D	oubl	le-a	oting							Remarks
Speed controller u	nit	Unit	TAIY0	SP-K017-Z03-006	0	0	0	0				0	0	0	0				Meter out control
Bypass unit			TAIY0	BP-K095-Z04-002	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
Five-port/2-position	Direct mounting	Single	TAIYO	PCS2406-K090-Z03-132-***					0							0			Exhaust throttle valve applied
non explosion-proof	_	Double	TAIYO	PCD2406-K090-Z04-120-***					0							0			to the solenoid valves as a
solenoid valve		Single	SMC	VFN2120N-****-02*					Ŏ							Ŏ			speed controller
		Double	SMC	VFN2220N-****-02*					ŏ							0			
Five-port/2-position		Single	Kaneko	MK15G-8-AE12PU-DMI					$\vdash$		0							0	
explosion-proof		_	Kaneko	MK15DG-8-AE12PU-DMI							0							0	
solenoid valve	l	Double														_		_	
Exhaust throttle va		For solenoid valves	Kuroda	MV-2-Z03-017					0		0					0		0	
Explosion-proof/ Non Explosion	Mounted with bracket	Non-standard	Kuroda	PCS2406/2408		-				0							0		
solenoid valve	Dracket	Non-standard	SMC	VF3130						0							0		
		Non-standard	CKD	4F2/4F3/4F4/4F5						0							0		
		Non-standard	Kaneko	M00U, M15G, MB15G, MG15G						0	0						0	0	
Filter regulator	Direct mounting		TAIYO	P31EA22EMMBNNP					0							$\circ$			Applicable to TAIYO
	Mounted with bra	acket	TAIYO	P31EA22EMMBNNP	0	0	0	0		0	0	0	0	0	0		0	0	solenoid valves only
			SMC	AW20	0	0	0	0		0	0	0	0	0	0		0	0	
Limit switch	Non-explosion-proof BOX type	Free-angle	Tomoe	TMS-3**-**-**-*	•				•	•	Ė	•				•	•		
	Non-explosion-proof -	90°	Azbil/OMRON	1LS1-J/WLCA2	•		•		i	•				Н		Ť	Ť		
	mounted with bracket		Azbil	VCL-5001	•		•		Ť	•				Н					
		80°,70°	Azbil/OMRON	1LS1-J/WLCA2	•		•			•				Н					
		00,70			_		-		÷	•				$\vdash$					
		Free '	Azbil	VCL-5001	•		•		•	•		_				_	_		
		Free-angle	Azbil/OMRON	1LS1-J/WLCA2								•		•		•	•		
			Azbil	VCL-5001								•				•	•		
	Explosion-proof -	80°,90°	Azbil	1LX-7001		•		0			0								
	mounted with bracket		Azbil	VCX-7001		•		0			0								
		70°	Azbil	1LX-7001		•		0			0								
			Azbil	VCX-7001		•		0			0								
		Open/Close detection	Azbil	VCX-7001		•		0			0								
		Free-angle	Azbil	1LX-7001									0		0			0	
		3	Azbil	VCX-7001									Ō		Ō			Ō	
Proximity switch	Direct mounting	90° only	Efector	IND2004		•			•	•								Ĭ	
TOXITILY SWITCH	Biroot mounting	oo only	OMRON	E2MP-CB1	•	•			•	•									
	Mounted with	00° 00° 70°	OMRON	(M18 shield) E2E-X7D1-N	-	•			÷	•			_	$\vdash$					
	Mounted with bracket	90°,80°,70°			•		•		•	_									
	and the second		OMRON	(M18 non-shield) E2E-X14MD1	•		•		•	•									
			OMRON	(M30 shield) E2E-X10D2-N	•		•		•	•							_		
		Free-angle	OMRON	(M18 shield) E2E-X7D1-N								•				•	•		
			OMRON	(M18 non-shield) E2E-X14MD1								•				•	•		
			OMRON	(M30 shield) E2E-X10D2-N	L							•		•		•	•		
Positioner	Electro-pneumatic		Tomoe(SSS)	TCE2000			0	0						0	0				
			Tomoe(SMC)	TP8100			0	0						0	0				
		Non-standard	Azbil	AVP300			Ŏ	Ŏ						Ŏ	Ŏ				
			SSS	XE/XP100-SB7			Ō	0						ŏ	Ö				
			SSS	XE/XP100-SS3			ŏ	ŏ		$\vdash$				ŏ	ŏ				
	Pneumatic-pneur	matic	SMC	IP5100			0	0						0	0				
Manual aparatics				11 0100	_\w1	<b>*</b> 2	Н			_w1		1 		0	~		∩w1		Manual lever applicable to:
Manual operating	ivialiuai ievel	BOX type	Tomoe			×2				0*1 0*1			0				0*1	0	T35, T85, T200, T380
	Olde I II	Spanner type	Tomoe		\%	×2	10	0	U <b></b> ∦1	U#1	V	∪#	U	0	0	∪#1	∪#	10	,
	Side handle		-		_				_				_			_	_		
	Manual gear		Tomoe		0	0	0	0	0	0	0	0		0		0		0	
ree angle adjuster	15 to 95°		Tomoe									0	0	0	0	0	0	0	
Valve Condition Monitoring Unit	For On-Off valve	With limit switch ouput	Tomoe	Tpro1100	•				•	•		•				•	•		
-		-		Non-explosion-proof specifications	0		0		0	0		0		0		0	0		
				Explosion-proof specifications	Ť	0	Ť	0	Ť	Ť	0		0	Ť	0		Ť	0	
				Solenoid valve		1			0	0	0			Н		0	0	0	
									۲	Н	$\vdash$			H		$\cup$	۲	$\vdash$	
				Positioner			0	0		$\vdash$				0	0	_			
				Free angle adjuster								0	0	0	0	0	0	0	
				Side handle															

O: Usable in combination  $lue{-}$ , $lue{-}$ : Only one of the  $lue{-}$ / $lue{-}$  marked items in each column can be used in combination

※1: Only spanner type available with TMS limit switch ※2: Manual lever unavailable with direct-mounted proximity switch

#### **New T-DYNAMO Standard Accessory Combination Chart**

■Single-action (spring-open type)

This chart indicates the accessories than can be used together in conjunction with the double-action cylinder. Only those items with a "O" mark in the same column can be used together.

Device name	Standard spe	cifications	Manufacturer	Fig.								Α	ir to	clos	e (s	pring	g op	en)							Remarks	
Speed controller u	nit	Unit	TAIYO	SP-K017-Z12-003-F		0	0	T	Т		00	0	0			0 (	0			0	0	0				
Bypass unit			TAIYO	BP-K095-Z04-002	П				T	П																
ive-port/2-position	Direct mounting	Single	TAIYO	PCS2406-K090-Z03-132-***	П				JT.	П								0					С		Exhaust throttle	
non explosion-proof		Double	TAIYO	PCD2406-K090-Z04-120-***	П		1		5	П							П	0	П				Ĉ		valve applied to	
solenoid valve		Single	SMC	VFN2120N-****-02*	H	П	1	1	Ħ	Ħ				_	H		Ħ	Ŏ	П		Н	_	C	П	the solenoid valves as a speed	
		Double	SMC	VFN2220N-****-02*	H	П	+	1	1	$\forall$				_	H		H	0				$\pm$	C		controller	
Five-port/2-position	-	Single	Kaneko	MK15G-8-AE12PU-DMI	Н	H	+	+	+	0	$\vdash$	+		+	0	+	H	+		) )	Н	+	+	-	0	
explosion-proof					H	$\vdash$	+	+	+	-	$\vdash$	+	$\vdash$	+	~	+	Н	+		) )	Н	+	+		9	
solenoid valve		Double	Kaneko	MK15DG-8-AE12PU-DMI	Ш	Н	4	+	+	0	$\vdash$			_	0							_				
Exhaust throttle va			Kuroda	MV-2-Z03-017	Ш	Н	4	4	4_	0	$\vdash$			4	0	_	Н	0	-	0	Н	4	C	-	9	
Explosion-proof/		Non-standard	Kuroda	PCS2406/2408	Ш	Ш	4	_	0					0			Ш		0					0		
Non Explosion solenoid valve	bracket	Non-standard	SMC	VF3130	Ш	Ш			0					0					0					0		
olonola valvo		Non-standard	CKD	4F2/4F3/4F4/4F5					0					0					0					0		
		Non-standard	Kaneko	M00U,M15G,MB15G,MG15G	П				0	0				0	0				0	<b>O</b>				0	5	
ilter regulator	Direct mounting		TAIYO	P31EA22EMMBNNP	П	П			5	П				5				0					С		Applicable to	
3	Mounted with bra	acket	TAIYO	P31EA22EMMBNNP				a l'	0			0	0	0		00		)	0	20		0	7		TÀİYO solenoid	
	I I I I I I I I I I I I I I I I I I I	aonot	SMC	AW20	0			_	10	-							0							0		
imit awitah	Non suplesion areaf DOV tune	Fran angla		TMS-3**-**-**	-	H	4	-			•	10	-	$\overline{}$	-						$\overline{}$	4	_	•		
_imit switch	Non-explosion-proof BOX type		Tomoe		Ť	$\vdash$			-	+	•		-	•	-			_	-	-		+	_			
	Non-explosion-proof - mounted with bracket	90°		1LS1-J/WLCA2	•	-	•	- 1		$\overline{}$	$\vdash$	1		_	-				•	-		+	+	$\vdash$	_	
	mounted with placket		Azbil	VCL-5001			•	_	•	$\overline{}$	$\perp$	1		$\perp$	$\rightarrow$				•			1	1	Ш		
		80°,70°		1LS1-J/WLCA2	•		•		•	'	Ш			$\perp$					•					Ш		
			Azbil	VCL-5001	•				•	1								•	•							
		Free-angle	Azbil/OMRON	1LS1-J/WLCA2	П		1	T			•	•		•						•		•	•	•		
		-	Azbil	VCL-5001	П			T	$\top$		•	•		•			П			•		•		•		
	Explosion-proof -	80°,90°	Azbil	1LX-7001	Н	•			+	•	Ť	Ť		+	П	•					Н	-	Ť			
	mounted with bracket	00,00	Azbil	VCX-7001	Н				+	•					H	•	-	7			$\Box$	+	+	H		
		70°	Azbil	1LX-7001	Н		_		+	-	$\vdash$			+	Н		-		-		H	+	+	Н		
		70			H	•	_	-	+	•	$\vdash$	_		+	Н	-	-	_	-	_	Н	+	+	Н	_	
			Azbil	VCX-7001	Ш	•	- 10	0	_	•	$\vdash$				Н	•		7	_	•	Н			Н		
		Open-close detection	Azbil	VCX-7001	Ш		_(	4	4	•	$\vdash$				Ш	•			(		Ш	_		Ш		
		Free-angle	Azbil	1LX-7001	Ш	Ш			$\perp$		C		0		0							_		_	2	
			Azbil	VCX-7001							C	)	0													
Proximity switch	Direct mounting	90°	Efector	IND2004					) (	•						•		•	•							
			OMRON	E2MP-CB1	•	•		(		•								•	•	Ð						
	Mounted with	90°,80°,70°	OMRON	(M18 shield) E2E-X7D1-N	•	Ť.	•	1		Ť						D	•	•	•			_		П		
	bracket	, , ,	OMRON	(M18 non-shield) E2E-X14MD1	•	П	•			-					$\vdash$		•		•		H	_				
			OMRON	(M30 shield) E2E-X10D2-N	•		•	- 1		$\perp$								Ť	•		$\Box$	+	+	H		
		Face and la			-	-	•			+	$\vdash$	-		+	-		•		•	+	Н	+	+		-	
		Free-angle	OMRON	(M18 shield) E2E-X7D1-N	•	H'	•	4	<b>"</b>	+	-		<b>.</b>		<u> </u>			•	•	_			-			
			OMRON	(M18 non-shield) E2E-X14MD1	Ш	Н		4	4	-	•	•	-				Ш			•	-	•	_	•		Actuat
			OMRON	(M30 shield) E2E-X10D2-N	Ш	Ш	4	4	$\perp$	Ш	•	•		•	Ш		Ш		Ш	•	Ш	•	+-	•		
Positioner	Electro-pneumatic		Tomoe(SSS)	TCE2000	Ш		0		$\perp$			0	0				0					-				New EL
			Tomoe(SMC)	TP8100	$\Box$	LT	0	2				0	$ \circ $					)				0		$\Box$		4 I
		Non-standard	Azbil	AVP300	П			oT.	Т	П		0					0	)	П			0				New MICOM E
			SSS	XE/XP100-SB7	П	$\rightarrow$	Ō	_	$\top$	П			Ō				0	_	П			0			1	PMK-S
			SSS	XE/XP100-SS3	H				+				Ö	$\top$					$\Box$			0				PIVIN-3
	Pneumatic-pneu	matic	Tomoe(SSS)	TCP2000	H	$\rightarrow$		_	+		H	_		+				_	+			0		+		SRJ
	i neumanc-pileu		SMC	IP5100	Н	-	_	_	+	+	+	_	-	+			1 -		$\vdash$					+		4J
Manual a 22	Manuali			IF 0100	$\vdash$	H		4	+	$\Box$	$\vdash$	10	0	+			00	1	<u> </u>			00	1		+	LTK
Manual operating			Tomoe	<u></u>	$\sqcup$	$\Box$	4	4	+	$\Box$		_		1		70	0	70	191	20	19	9	낃	191		4L
ree angle adjuster	15 to 90°		Tomoe	Attached to side cover	₽		4	4	$\perp$	Ш	00	70	1010	00	Q		Н		Н			4	1	Н	Side handle unavailable	New T-DYN
	Side handle avail	lable	Tomoe	Attached to side cover	Ц	Ш		1	$\perp$		$\perp$			$\perp$			Ш		Ш					Ш		7E/7F/
	0 to 94°		Tomoe	External unit(%1)	L				$\perp$											0				0	0	TGA
/alve Condition	F 0- 0"	With limit	T	T1400						П		Т														3A
Monitoring Unit	For On-Off valve	switch ouput	Tomoe	Tpro1100					•	1	•								•	•						TG-9
	1	σαραί		Non-explosion-proof specifications	0	$\Box$	ol	10	10	+	0	0			1	7		0				0		0		
				<del></del>	H		-		#	-		-	0	7	<del>   </del>	0	<del>   </del>	1	Η,			-	5	_	5	3C
				Explosion-proof specifications	H	14	-1	~	+			4	-	00		10	H	1			1	1				Diaphra
				Calamaid calc:							. 1			11( )	11 M		1 1	-10	41 110		1		- 1( '			
				Solenoid valve	$\vdash$	$\vdash$	$\perp$	_	<u> </u>	14	4	_	-	4	М		٦.		4	_	H			M	4	6X/6W/6Z/
				Positioner			0		$\perp$			0	0				0					0	)			Hydraulic cy
							0	_				0	0		0		00	)		C	0	000	) ) (	00	0	6X/6Ŵ/6Z/6 Hydraulic cy 3H Manual Actu

O: Usable in combination  $\bullet$ , $\bigcirc$ : Only one of the  $\bullet$ / $\bigcirc$  marked items in each column can be used in combination ※1: Free-angle adjuster unit is installed in between valve and cylinder



#### **New T-DYNAMO Standard Accessory Combination Chart**

#### ■Single-action (spring-shut type)

This chart indicates the accessories than can be used together in conjunction with the double-action cylinder. Only those items with a "O" mark in the same column can be used together.

Device name	Standard spe		Manufacturer	Fig.	ļ.,	_					_	_		00	pen		ring		<del></del>				1 - 1		,		Remarks
Speed controller u	nit	Unit	TAIYO	SP-K017-Z03-006	0	0 0	) (C	)	Ш		0	0	0	_		0	0		Ш		C	0	0	0	$\perp$		
Bypass unit		ı	TAIYO	BP-K095-Z04-002					Ш				Ш						Ш				Ш	4			
Five-port/2-position	Direct mounting	Single	TAIYO	PCS2406-K090-Z03-132-***	Ш			0	Ш				Ш	<u> </u>										_	0		Exhaust throttle
non explosion-proof solenoid valve		Double	TAIYO	PCD2406-K090-Z04-120-***	Ш			0						0										(			valve applied to the solenoid
Sololiola valvo		Single	SMC	VFN2120N-****-02*				0						0										(	C		valves as a speed
		Double	SMC	VFN2220N-****-02*				0						0										(	Э		controller
Five-port/2-position		Single	Kaneko	MK15G-8-AE12PU-DMI						0					C	)				(	0					0	
explosion-proof solenoid valve		Double	Kaneko	MK15DG-8-AE12PU-DMI						0					C	)				(	0					0	
Exhaust throttle va	lve	For solenoid valves	Kuroda	MV-2-Z03-017				0		0				0	0	)				(	9			(	О	0	
Explosion-proof/	Mounted with	Non-standard	Kuroda	PCS2406/2408	П				0						0				П	0				П	(	)	
Non Explosion solenoid valve	bracket	Non-standard	SMC	VF3130					0					(	0					0					(	)	1
Sulcifuld valve		Non-standard	CKD	4F2/4F3/4F4/4F5					0					(	0				П	0				T	(	)	1
		Non-standard	Kaneko	M00U,M15G,MB15G,MG15G					0	0			П		00	)			П	0	Э				(	00	1
Filter regulator	Direct mounting		TAIYO	P31EA22EMMBNNP	П			0				T	П	ol									П	1	ol		Applicable to
3	Mounted with br	acket	TAIYO	P31EA22EMMBNNP	0	00		)		0	olo		0	(	olc	0		0	H	0	)(	0	0	0	- (		TÀIYO solenoid
			SMC	AW20	Ō			_	-		0			$\rightarrow$						0				Õ			Jualuae anlu
Limit switch	Non-explosion-proof BOX type	Free-angle	Tomoe	TMS-3**-**-**-*	•			-	-	$\overline{}$	•	1	Ŭ	•	_	•		1	-	•		_		-	•	-	
	Non-explosion-proof -	90°	Azbil/OMERON			4		_	•	1							-		-	•			H	+	+	+	1
	mounted with bracket		Azbil	VCL-5001	•				•				Н	+	t	•			•	-	+		H	+	+		†
		80°,70°	Azbil/OMERON		•		_		•	_	+	+	Н	+	+		-		•	- 1	+	+	H	+	+	+	1
		00 ,70	Azbil	VCL-5001		-	_	•		+	+	+	$\vdash$	+	+	-			ŏ		+	+	H	+	+	+	1
		Free-angle	Azbil/OMERON		_	_		•		-	•	•	Н	•		_						+	•	۲,	•		1
		riee-angle	Azbil/OWENON	VCL-5001	Н	+		-		$\rightarrow$	•	•	-		_				Н			-	•	-		_	1
	Evaluation proof	00° 00°					С		Н	_ '	•	-	Н	<b>"</b>					Н			<u>'</u>	•		_	4	-
	Explosion-proof - mounted with bracket		Azbil	1LX-7001		•			Н		_	+	Н	+			•	0	-			╁		+	+		-
		70°	Azbil	VCX-7001	Н		С	-			_	+	Н	+			•	0	-			+	Н	+	-	+	-
		70°	Azbil	1LX-7001	Н	•	С	_	Н	•	_	+	Н	4	+	-	•	0	-	-		+	Ш	4	_	+	-
			Azbil	VCX-7001		•	С	_	Н	•	4	1	Ш		-		•	0	-	-				4		+	-
			Azbil	VCX-7001			С	)	Н			_		$\perp$		-	•	0	Ш					_	_		-
		Free-angle	Azbil	1LX-7001					Ш			_	0	4	C	_	Ш		Ш		+	0	Ш	0	4	С	
			Azbil	VCX-7001					Ш			1	0	4	С	-			Ш		+	0		0		С	
Proximity switch	Direct mounting	90°	Efector	IND2004	•	•		•		-	4		Ш	4		•	•		-	•	_			4			
			OMERON	E2MP-CB1	•	•		•	_	•			Ш	4		•	•		-	•		L	Ш				
	Mounted with	90°,80°,70°	OMERON	(M18 shield) E2E-X7D1-N	•	•	_	•								•				-							
	bracket		OMERON	(M18 non-shield) E2E-X14MD1	•	•			•							•											
			OMERON	(M30 shield) E2E-X10D2-N	•	•		•	•							•			_	•							
		Free-angle	OMERON	(M18 shield) E2E-X7D1-N	•	•		•								•											
			OMERON	(M18 non-shield) E2E-X14MD1							•	•		•	•						•		•	-	•		]
			OMERON	(M30 shield) E2E-X10D2-N							•	•		•	•						•	)	•	(	•		1
Positioner	Electro-pneumatic		Tomoe(SSS)	TCE2000			) C					0	0						П				0	0			
			Tomoe(SMC)	TP8100			) C		П			0	0	T									0	0			1
		Non-standard	Azbil	AVP300	П		0	)	П			0	0	T				00	П		T			o			1
			SSS	XE/XP100-SB7	П		0		П			Ō	-	T		Т			-		T	T		Ō	T		1
			SSS	XE/XP100-SS3			0		П			Ō	-	T					-			t		Ō			1
	Pneumatic-pneu	matic	SMC	IP5100	H		) C					0	-	+			-		-		t	t	-	Ö			1
Manual operating		matio	Tomoe	11 0100	H				H	1		ľ	М	1		0	0								7		
Free angle adjuster			Tomoe	Attached to side cover	H			t	H						00		H		H	Ť	7	Ť	Ť	7	+		Side handle unavailal
so ungio dujustoi	Side handle available	lahle	Tomoe	Attached to side cover	H			H	H	+		1	H	7		+			Н	$\vdash$	+		H	+			Side nandie unu ralia
	0 to 94°	14.010	Tomoe	External unit (%1)	H				H	+		1	Н	+	t				Н	H	1		0				
Valve Condition	0 10 37	With limit	1011100	EXIOTIAL UTILL (28-1)	Н	+		+	Н	+		+	$\vdash$	+	+	+			Н	+			Н				
Monitoring Unit	For On-Off valve		Tomoe	Tpro1100	•			•			•			•	•	•				•	•			(	•		
wontoning Unit		switch ouput		Man avalacian proof anasifications		1				-	0		Н								1			+			
				Non-explosion-proof specifications	0		_	0	-	$\rightarrow$	-	10	-	9	_		-		-	-		-	0	_		_	-
				Explosion-proof specifications	Н	9	С			의		1	0	$\dashv$	C	1	0	0				0	Н	0	1.	C	
				Solenoid valve	Н				0	9		1		9	) C	)				0	7					) C	1
				Positioner	Ц		0		Ц			10	0					0	Н		1	-		0			1
				Stroke adjuster	Ц				Ц	-			0	이	) C	)			Ц				0				
				Manual gear unit												10	0		10			00	0	0			1

●,◎: Only one of the ●/◎ marked items in each column can be used in combination O: Usable in combination

※1: Free-angle adjuster unit is installed in between valve and cylinder

#### **New T-DYNAMO Solenoid valves**

#### Purpose

The purpose of a solenoid valve is to use electrical signals to remotely change the air flow to operate the valves.

#### Standard specifications

Туре	Five-port/2-position non explosion-proof	Five-port/2-position non explosion-proof	Five-port/2-position explosion-proof	Five-port/2-position explosion-proof		
турс	solenoid valve (single solenoid)	solenoid valve (double solenoid)	solenoid valve (single solenoid)	solenoid valve (double solenoid)		
Tem PCS2406-K090-Z03-132-**		PCD2406-K090-Z04-120-**	MK15G-8-※-DMI	MK15DG-8-※-DMI		
Manufacturer	TAIYO	TAIYO	Kaneko	Kaneko		
JIS symbol	R1 A B B	R1 A B B	1	1 2 3 3 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		
Applicable cylinder type	T35 to T750/T85S to T750S	T35 to T750/T85S to T750S	T35 to T750/T85S to T750S	T35 to T750/T85S to T750S		
Mounting method	Direct mounting	Direct mounting	Direct mounting	Direct mounting		
Air connection port size	Rc1/4 (IN, EXH)	Rc1/4 (IN, EXH)	Rc1/4 (IN, OUT, EXH)	Rc1/4 (IN, OUT, EXH)		
Effective sectional area	10mm <sup>2</sup>	10mm <sup>2</sup>	20mm <sup>2</sup>	20mm <sup>2</sup>		
Rated voltage AC100V/110V 50/60Hz AC200V/220V 50/60Hz DC24V		AC100V/110V 50/60Hz AC200V/220V 50/60Hz DC24V	AC100V 50/60Hz AC110V/200V 50Hz AC220V 60Hz DC24, 100, 110, 125V	AC100V 50/60Hz AC100V, 200V 50Hz AC220V 60Hz DC24, 100, 110,125V		
Class of insulation	-	-	d2G4	d2G4		
Wiring method	Conduit terminal	Conduit terminal	Conduit terminal	Conduit terminal		
Conduit entry	G1/2	G1/2	G1/2	G1/2		
Manual operating	Non lock bush type	Non lock bush type	Manual botton lock type	Manual botton lock type		
Operating temperature	-5 to 50 degrees C	-5 to 50 degrees C	-20 to 60 degrees C	-20 to 60 degrees C		
Weight	0.2kg	0.27kg	1.2kg	1.7kg		

Remark: The above are standard TOMOE-compatible solenoid valves. It is also possible to install solenoid valves other that those listed above such as a double solenoid or 3-port solenoid valve. For details, please consult us.

#### New T-DYNAMO Filter regulators (Pressure reducer with filter)

#### Purpose


Filter regulators are used to eliminate oil, water, and dust from the operating air in order to protect pneumatic accessories (solenoid valve and cylinder, etc.) and to keep operating pressure at an adequate and constant level (about 4 to 5 K).

#### Standard specifications

	<u> </u>			
Туре	P31EA22EMMBNNP			
Manufacturer	TAIYO			
JIS symbol				
Applicable cylinder type	T35 to T750/T85S to T750S			
Set pressure range	0.03 to 0.85MPa			
Pressure gauge connection port	Rc1/8			
Operating temperature	—5 to 60 degrees C			
Air connection port size	Rc1/4			
Filtration	5µm			
Attachment	Direct mounting			
Option	_			
Weight	0.19kg			

Remark: The above are standard TOMOE-compatible filter regulators.

It is also possible to install filter regulators other that those listed above. For details, please consult us.







#### **New T-DYNAMO Limit switches**


#### Purpose

Limit switches are used to convert the valve position (full close, full open, half open) into electric signals for lamp indication at a remote location.

#### Standard specifications

Туре	TMS-B0X		1LS1-J WLCA2	1LX-7001	VCX-7003		
Manufacturer	Tomoe		Azbil (1LS1-J) OMRON (WLCA2)	Azbil	Azbil		
	Monopolar double-throw(1C, SPDT)X2		Bipolar double interruption (1A1B, 2CKT-DB)	Bipolar double interruption (1A1B, 2CKT-DB)	Monopolar double-throw (1C, SPDT) X2		
Circuit	сом —	NC NO	(NO) 4 (NO) 3 (NC) 1 (NC) 2	(NO) 4 (NO) 3 (NC) 1 (NC) 2	COM NO		
	,,,,		(110)		110		
Actuator	Hinge roller lever type		Roller lever type	Roller lever type	Adjustable roller lever type		
Class of insulation	IP67 (Option: ExdIIBT6)		IP67	IP67, Exde IIC T6	IP67, Exde IIC T6		
	Standard	Micro load specificaions	AC125V-10A	AC125V-5A	AC250V-5A		
Rated voltage	AC250v-1.6A	AC125V-0.1A	AC250V-10A	AC250V-5A	DC125V-0.8A		
(resistance load)	DC125V-0.6A DC30V-0.1A		AC480V-10A	DC125V-0.8A	DC250V-0.4A		
(16313tarioc 16au)			DC125V-0.8A	DC250V-0.4A			
			DC250V-0.4A				
Minimum applicable load	DC30V 100mA DC5V 1mA		DC24V 10mA(1LS1-J)	DC24V 10mA	DC24V 10mA		
(reference value)	DG30V TOOTHA	DG3V IIIIA	DC5V 160mA(WLCA2)	DG24V TOTTA	DG24V TOTTA		
Operating temperature	-10 to 80 degrees C		1LS1-J: —10∼70°C	-10 to 60 degrees C	40 to 60 do		
operating temperature — 10 to 60 degrees C		WLCA2:-10~80°C	— To to do degrees c	—10 to 60 degrees C			
Conduit entry	2-G1/2		G1/2	G1/2	G3/4		
Option	_		Heat, cold and corrosion resistant	Hydrogen anti-explosion (1LX7001)	Waterproof (VCL-5003)		
Contacts	Switch detection with	one	On or off detection with one	On or off detection with one	Switch detection with one		
CUITACIS	(2 switches inside)		Two for both on and off detection	Two for both on and off detection	(2 switches inside)		
Weight	0.98kg		0.28kg	0.74kg	0.77kg		

Remark: The above are standard TOMOE-compatible limit switches. It is also possible to install limit switches other that those listed above. For details, please consult us. Since the rated load of the TMS-BOX micro load specification is smaller than that of the standard specification, a failure may occur if a current exceeding the rating is applied.



#### **New T-DYNAMO Proximity switches**


#### Purpose

Proximity switches are used to convert the valve position (full close, full open, half open) into electric signals for lamp indication at a remote location.

#### **■**Standard specifications

Product	M18 shielded type (Can be embedded in metal.)	Direct-mounting proximity switch		
Type	E2E-X7D1-N	IND2004DARKG		
Manufacturer	OMRON	efector		
With power source	DC 2-wire system	DC 2-wire system		
Motion mode	NO	NO		
Detecting distance	0 to 5.6mm	4mm±10%		
Object to be detected	Magnetic metal (stainless steel possible)	Dedicated target		
Power source voltage	DC12 to 24V	DC10 to 36V		
Current consumption	3 to 100mA	min 4mA		
Class of insulation	IP67	IP67		
Operating temperature	-25 to 70 degrees C	-25 to 80 degrees C		
Connection	Cord draw type (2m)	Cord draw type (2m)		
Contacts	On or off detection with one	2-point switch detection possible		
CUITAGES	Two for both on and off detection	with a single unit		
Weight	0.43 kg (including mounting plate): 1 piece	0.23 kg (including mounting plate): 1 piece		

Remark: The above are standard TOMOE-compatible proximity switches. It is also possible to install limit switches other that those listed above such as a DC 3-wire, AC 2-wire, AC/DC 2-wire or connector-type proximity switch. For details, please consult us.



New MICOM ELMY II PMK-SRF SRJ 4J LTKD 4L New T-DYNAMO 7E/7F/7G TGA 3A TG-S 3K/3U **3C** Diaphragm 6X/6W/6Z/6A/6B Hydraulic cylinder 3 H Manual Actuators 1T/1J/2U/2I/2S/2G/2R



#### **New T-DYNAMO Positioners**


#### Purpose

A positioners are used for quick and accurate control of the valve opening angle with pneumatic signals or 4-20mA DC input signals from a control room or controller unit.

#### Standard specifications

	Electro-Pneumatic, analog	Electro-Pneumatic, analog	Pneumatic-Pneumatic	
Туре	TCE2000	TP8100	IP5100	
Manufacturer	Tomoe	Tomoe	SMC	
Input signal	4 to 20mA	4 to 20mA	0.02 to 0.1MPa	
Resistance	250Ω (4 to 20mADC)	235±15Ω (4 to 20mADC)	_	
Supply air	0.14 to 0.7MPa	0.14 to 0.7MPa	0.14 to 0.7MPa	
Output flow rate	180L/min.(ANR) or more (SUP=0.4MPa)	200L/min.(ANR) or more (SUP=0.4MPa)	200L/min.(ANR) or more (SUP=0.4MPa)	
Air consumption	Within 11L/min.(ANR) (SUP=0.4MPa)	Within 11L/min.(ANR) (SUP=0.4MPa)	Within 11L/min.(ANR) (SUP=0.4MPa)	
Operating temperature	—20 to 83 degrees C (Non explosion-proof)	—20 to 8 degrees C (Non explosion-proof)	-20 to 80 degrees C	
Operating temperature	-20 to 60degrees C (Explosion-proof type d2G4)	—20 to 60 degrees C (Explosion-proof)		
Class of insulation	IP65, Exd∏BT6X	IP65, Exd∏BT5	_	
Air connection port size	Rc1/4	Rc1/4	Rc1/4	
Conduit entry	2-G1/2	2-G1/2	_	
Sensitivity	Within 0.5%FS	Within 0.5%FS	Within 0.5%FS	
Linearity	Within ±1.5%FS	Within ±2%FS	Within ±2%FS	
Hysterisis	Within 1%FS	Within 1%FS	Within 1%FS	
Option	<del>-</del>	_	_	
Weight	2.3kg	2.6kg	1.2kg	

Remark: The above are standard TOMOE-compatible positioners. It is also possible to install positioners other that those listed above. For details, please consult us.




# New T-DYNAMO Manual operation unit

#### Purpose

The operation unit is for manual operation of the pneumatic cylinder when air supply fails.

#### ■Standard specifications

	Function	Туре	Applicable cylinder	Manual Operation Procedure	Remarks	
1	Manual lever	Lever	T35, T85, T200, T380 (Double-acting)	<ul><li>(1) Open the bypass valve.</li><li>(2) Turn the center axis using a spanner.</li></ul>	Never use for any single acting type cylinder.     Do not input signal to the solenoid valve or positioner during operation.	
2	Side handle	Screw handle	T85S, T200S, T380S, T750S (Single-acting)  (1) Open the bypass valve. (2) Turn the handwheel in accordance with the direction indicated on the nameplate located in the middle of the manual screw handle to open and close the valve.		<ul><li>(1) Do not input signal to the solenoid valve or positioner during operation.</li><li>(2) Restore the valve angle in the position air supply shutted off when restarting the automatic operation.</li></ul>	
3	Manual gear unit	Worm gear	T200, T380, T750 (Double-acting)	Remove residual pressure from the cylinder.     Turn the handwheel.	(1) Do not input signal to the solenoid valve or positioner during operation.      (2) Restore the valve angle in the position air supply shutted off when restarting the automatic operation.	








#### **New T-DYNAMO Free-angle adjuster**

#### Purpose

Free-angle adjuster enables to set open/close angle depending on users' demand.

#### Standard specifications

Function	Туре	Applicable cylinder	Remarks
Free-angle adjuster	Side adjust screw	T35 to T750/T85S to T750S (Air to open)	Remove the cylinder cover, loosen the lock nut and insert the bolt to adjust the stroke angle.  Tighten the lock nut and attach the cylinder cover in position.



#### **New T-DYNAMO Speed controllers**


#### Purpose


For double-acting cylinders, the speed controller is used as meter out (exhaust throttle) and for single-acting cylinders, it is used as meter in (suction throttle).

#### Standard specifications

Туре	MV-2-Z03-017	SP-K017-Z03-006					
Manufacturer TAIYO		TAIYO					
JIS symbol							
Applicable cylinder type	With PCS 2406-K090-Z132 solenoid valve mounted	Other than indicated at left					
Function	With silencer	_					
Needle revolution	10 rotations	11 rotations					
Adjustable range	5 to 15 secs.	5 to 15 secs.					
Air connection port size —		Rc1/4					
Attachement	Screw into solenoid valve exhaust port (Rc 1/4)	Install to cylinder					
Weight	0.06kg	0.095kg					

Remark: The above are standard TOMOE-compatible speed controllers. It is also possible to install speed controllers other that those listed above. For details, please consult us.






#### **New T-DYNAMO Silencers**

#### Purpose

Silencers eliminate noise at the exhaust ports on various kinds of pneumatic accessories.

#### Standard specifications

Туре	AN10-C06	AN20-02				
Manufacturer	SMC	SMC				
JIS symbol						
Applicable cylinder type	T35 to T750/T85S to T750S	T35 to T750/T85S to T750S				
Effect of muffing	25dB (A)	30dB (A)				
Operating temperature	5 to 60 degrees C	5 to 60 degrees C				
Port size	$\phi$ 6	Rc1/4				
Attachement	Install to exhaust port together with one-touch pipe coupler.	Screw into exhaust port.				
Weigh	0.02kg	0.02kg				



Remark: The above are standard TOMOE-compatible silencers. It is also possible to install silencers other that those listed above. For details, please consult us.

#### **New T-DYNAMO Lock-up valves**


#### Purpose

When air supply fails, the lock-up valve automatically stops the line until pressure is restored and keeps the operating unit of the cylinder at the stay-put position.

#### Standard specifications

Type	IL211-02	IL201-02		
Manufacturer	SMC	SMC		
JIS symbol				
Applicable cylinder type	T35 to T750	T85S to T750S		
Effective sectional area	17mm²	17mm²		
Operating temperature	-5 to 60 degrees C	-5 to 60 degrees C		
Air connection port size	Rc1/4	Rc1/4		
Signal pressure connection port	Rc1/4	Rc1/4		
Weight	0.64kg	0.43kg		

Remark: The above are standard TOMOE-compatible lock-up valves. It is also possible to install lock-up valves other that those listed above. For details, please consult us.









#### New T-DYNAMO Examples of standard air circuits for pneumatic actuators


# Standard and semi-standard accessories and their use Example of standard air circuit for on/off operation (double-acting type)

Shown below are standard circuits to open and close a butterfly valve driven by a double-acting air cylinder while transmitting electrical signals from a remote control room. Switching of the flow of operation air is performed by the solenoid valve, and detection of the open/close position of the valve is performed by a limit switch, with feedback of the electrical signals to the control room.



2 Butterfly valve closes when solenoid valve is energized.





→Once SOL.1 is energized, the condition is maintained even after it is de-energized unless SOL.2 is energized


#### New T-DYNAMO Example of standard air circuits for pneumatic actuators

#### Example of standard air circuit for control operation (double-acting type)

Shown below are examples of standard circuits in which a P/P or E/P positioner is attached to the butterfly valve driven by a double-acting pneumatic cylinder to give instruction signals from a remote control room to the positioner. This adjusts the valve opening exactly and quickly in proportion to the signals, and also detects the open/close position of the valve by a limit switch which sends feedback of the electrical signals to the control room.


#### 4 Direct action

Butterfly valve closes when signal increases. Butterfly valve opens when signal decreases.



→The butterfly valve opens fully when the input signal goes off under a state of assured air supply.

#### 5 Reverse action Butterfly valve opens when signal increases. Butterfly valve closes when signal decreases.



→The butterfly valve closes fully when input signal goes off under a state of assured air supply.






#### New T-DYNAMO Example of standard air circuits for pneumatic actuators


#### Example of standard air circuit for on/off operation (single-acting type)

Shown below are examples of standard circuits to operate the valve automatically to the safe side of open or close when the operating air supply or power supply fails in the middle of operation.

1 Butterfly valve closes when air supply falls. (Opened by pressure when solenoid valve is energized.) Butterfly valve closes when power supply falls.



2 Butterfly valve opens when power supply falls. (Closed by pressure when solenoid valve is energized.) Butterfly valve opens when air supply falls. (Closed by pressure when solenoid valve is energized.)




#### New T-DYNAMO Example of standard air circuits for pneumatic actuators

#### Example of standard air circuit for control operation (single-acting type)

Shown below are examples of standard circuits in which the P/P or E/P positioner is attached to the butterfly valve driven by a single-acting pneumatic cylinder to adjust valve opening exactly and quickly in proportion to the signals transmitted by a local controller or from a remote control room. This will also detect the open/close position of the valve by a limit switch which sends feedback of the electric signals to the control room. When the operating air supply or power supply fails, the valve is automatically operated to the safe side of open or close.

#### 3 Direct action


Butterfly valve closes when signal increases. Butterfly valve opens when signal decreases.



→Butterfly valve opens when air supply fails.

#### 4 Reverse action

Butterfly valve opens when signal increases. Butterfly valve closes when signal decreases.



→Butterfly valve closes when air supply fails.

# **Actuator New ELMY** New MICOM ELMY I PMK-SRF SRJ LTKD New T-DYNAMO 7E/7F/7G TGA TG-S 3K/3U **3C** Diaphragm 6X/6W/6Z/6A/6B Hydraulic cylinder 3 H Manual Actuators

1T/1J/2U/2I/2S/2G/2R